



FH-440 XR Front Hitch

Owner's Manual & Parts Book

Grouser Products

755 2nd Ave NW - West Fargo, ND 58078

Phone: 1-800-747-6182

Fax: 1-701-282-8131

E-mail: grouser@grouser.com

Website: www.grouser.com

Purchase Date
Serial Number
Model Number
Tractor Model
Dealer

Description	Page
Welcome To The Owner _____	2
Safety Precautions & Torque Specifications _____	3
Decals _____	4
Maintenance & Lubrication _____	5
Lift System _____	6-7
Tractor Side Hydraulics _____	8-9
Hydraulic Schematic _____	10
Contact Us, Improvements, & Warranty _____	12

Thank you for your recent purchase of a Grouser FH-440 XR Front Hitch. Welcome to the family of satisfied Grouser Front Hitch owners. Grouser Products is committed to offering quality products to help professionals in their daily jobs. We are also committed to providing you the highest level of customer satisfaction possible. Again, thank you for your patronage. We look forward to serving you.

This manual contains information concerning the operation, adjustment, safety and maintenance of the FH-440 XR Front Hitch. You have purchased a dependable, long lasting piece of equipment. You can expect to receive long lasting performance and long service built into our products with proper care and operation. Please have all operators read and understand this manual carefully. Keep the manual available for reference. If, for any reason, you have questions or comments, we would be happy to hear from you. Call our toll-free number, 800-747-6182, or send us an e-mail at info@grouser.com. You can expect us to respond to your e-mail in a timely manner.

A careful operator is the best operator. Most accidents can be avoided by observing certain precautions. To help prevent accidents, read and take the following precautions before operating this equipment. In addition, please follow all safety and operational instructions of your tractor manufacturer.

The FH-440 XR Front Hitch:

1. The FH-440 XR Front Hitch should be operated only by those who are responsible and instructed to do so.
2. Read the owner's manual carefully before using this equipment. Lack of operating knowledge can lead to accidents.
3. Keep the Front Hitch maintained in reliable and satisfactory condition to ensure your safety.
4. Make sure the area is clear of people before moving any equipment.
5. Do not modify or permit anyone else to modify or alter the equipment and its components without first consulting Grouser Products.
6. Lower the blade to the ground when not in use.

Servicing the FH-440 XR Front Hitch:

1. Read and follow all safety instructions provided by the tractor manufacturer.
2. Always use proper personal safety gear when performing maintenance on equipment.
3. Before servicing, relieve hydraulic pressure, stop engine and fully engage parking brake.
4. Escaping hydraulic fluid under pressure can penetrate skin causing serious injury. If fluid is injected into skin, obtain medical attention immediately.
 - DO NOT use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks.
 - Stop the engine and relieve pressure before connecting or disconnecting lines.
 - Tighten all connections before starting the engine or pressurizing lines.


Storing the FH-440 XR Front Hitch:

1. Thoroughly clean the inside and outside of the Front Hitch before storage. Use paint where necessary to prevent rust.
2. Check the Front Hitch for worn or damaged parts. Install new parts as required.
3. Lubricate all pins and joints.

Tighten all bolts to the values listed below unless otherwise noted. Refer to the parts lists for proper length and grade of the bolts.

Size	Torque - Dry (ft-lbs)			
	SAE Grade 5		SAE Grade 8	
	UNC	UNF	UNC	UNF
5/16	17	19	24	27
3/8	30	35	45	50
7/16	50	55	70	80
1/2	75	85	110	120
9/16	110	120	150	170
5/8	150	170	210	240
3/4	260	300	380	420
7/8	430	470	600	670
1	640	720	910	1020

Size	Torque - Dry (ft-lbs)
	Grade 10.9
M18 x 2.50	284
M20 x 2.50	401
M22 x 2.50	547
M24 x 3.00	694



WARNING

PINCH AREA
Keep away

Failure to comply could result in death or serious injury.

27-2409

PN: 27-2409

WARNING

PINCH POINT

AVOID INJURY FROM
FRAME PIVOT AND STOPS.

- Keep hands and feet away.

27-9503

PN: 27-9503

Left and Right Side

WARNING

INSURE THERE IS
ADEQUATE CLEARANCE
BETWEEN TIRES AND BACK
OF BLADE SYSTEM


SEE OWNER'S MANUAL FOR
CORRECT EXTENSION TO
GAIN ADEQUATE CLEARANCE

27-40425

PN: 27-40425


Due to the harsh environment this equipment operates in, the following tasks should be performed every 10 hours or less.

- Inspect all equipment before operation for existing or potential damage.
- Lubricate all joints with high quality grease. See below for grease locations.
- Inspect all bolts, and tighten any loose bolts to torque specifications on page 3.
- Check hydraulic cylinders and hoses for damage or leaks. For replacement parts, see hydraulic pages for your specific system.
- Make sure all non-rotating pins are secured properly.
- Inspect all decals and order replacement decals from your dealer if any are damaged or worn.
- Replace parts with original parts only.




	Grease Locations
Lift System	12


ITEM NO.	Qty.	PART NO.	DESCRIPTION
1	1	11-16918	Pin Pulling Arm Assembly
2	1	11-42535	Lower Arm
3	1	11-42540	Top Arm
4	5	16-17266	3/8" x 3/4" Flange Button Socket Cap Bolt
5	1	16-20011	1/4" x 2-3/4" Hex Bolt Gr 5 NC
6	2	16-20035	5/16" x 1-1/4" Hex Bolt Gr. 5
7	8	16-20125	1/2" x 1-1/4" Hex Bolt Gr 5 NC
8	2	16-20424	1/2" x 3-1/2" Hex Bolt Gr 8 NC
9	2	16-21065	3/8" x 1-1/4" Carriage Bolt Gr 5 NC
10	4	19-16328	2.75 x 2.50 x 2.00 Spring Bushing
11	4	19-40419	2.25 x 2.00 x 1.38 Spring Bushing
12	2	19-40440	.378" ID x .503" OD x .375" Spacer
13	4	19-7954	2.25 x 2.00 x 2.00 Spring Bushing
14	1	26-34761	5 x 14 - Cylinder 2" ID Tube Ends
15	2	27-17263	FH-440 Decal
16	1	27-2409	Pinch Decal (Hand)
17	1	27-40425	Warning Decal - Torque Arm
18	2	27-42452	XR Decal
19	1	27-9503	Pinch Decal (Foot)
20	2	27-9504	Grouser Horizontal Decal
21	1	34-14961	Manual Canister Small
22	1	34-17799	Latch Spring
23	1	39-16931	Latch
24	1	39-3072	Rubber Handle



DETAIL A




ITEM NO.	Qty.	PART NO.	DESCRIPTION
25	4	43-16385	Top Pin Assy.
26	4	43-16390	Bottom Pin
27	2	43-18405	Cylinder Pin
28	2	43-40765	Pin, 240 Lock Out
29	1	45-18300	Quick Attach
30	2	57-20741	5/16" Flat Washer
31	2	57-20742	3/8" Flat Washer
32	5	57-20792	3/8" Fender Washer
33	8	57-20794	1/2" Fender Washer
34	4	57-40408	3/8" Flat Nylon Washer
35	10	58-9369	Straight 1/8" NPT Grease Zerk
36	2	70-20604	1/2" Center Lock Hex Nut
37	1	70-20610	1/4" Nyloc Hex Nut Gr 5 NC
38	2	70-20611	5/16" Nyloc Hex Nut Gr. 5
39	2	70-20612	3/8" Nyloc Hex Nut Gr 5 NC
40	1	75-16915-L	Link Assembly
41	1	75-16915-R	Link Assembly




Note: When ordering cylinder seal kits, the part number on the cylinder is needed. The number is stamped on the base end of the cylinder opposite of the hydraulic ports.


No. On Cylinder	Part No.	Description
26-34761	49-12277	Seal Kit 5 x 14 - Nitrided Rod




DETAIL A
Cylinder View From Right Side



ITEM NO.	PART NO.	HAHT & LIFT Qty.	HANT & LIFT QTY.	NANT & LIFT QTY.	DESCRIPTION
1	16-20046	1	-	-	5/16" x 4" Gr 5 Hex Bolt
2	16-20040	-	1	-	5/16" x 2-1/2" Hex Bolt Gr 5 NC
3	16-35C612	4	2	-	3/8" x 3/4" Flange Bolt
4	18-19311-03-P-087	2	1	-	Hose Clamp
5	18-19312-03	1	1	-	Twin Cover Plate
6	25-34321	4	2	-	Female Pioneer Coupler
7	25-34342	6	4	2	Tappet Quick Coupler Male - Poppet Style
8	25-3453	2	-	-	Pioneer Dust Cap Tilt (Green)
9	25-3454	2	-	-	Pioneer Dust Plug Tilt (Green)
10	25-3455	2	2	-	Pioneer Dust Cap Angle (Red)
11	25-3456	2	2	-	Pioneer Dust Plug Angle (Red)
12	25-3457	2	2	2	Pioneer Dust Cap Lift (Orange)
13	31-11699-8-8	1	1	1	JIC Union
14	31-34051	12	8	4	Straight Thread Elbow 90° JIC x O-Ring
15	34-12932	1	1	1	Cylinder Saddle
16	34-12933	1	1	1	Hose Clamp (worm drive - 5.0)
17	34-18888-RD	6	6	-	-12 Red - Spiral Band
18	34-18888-GR	6	-	-	-12 Green - Spiral Band
19	34-18888-OR	6	6	6	-12 Orange - Spiral Band
20	35-17721-280-1	2	2	2	280" (23.3") x 1/2" -8JIC/-8JIC Hose w/Cordura
21	35-40780	1	1	1	Tube Assembly
22	35-42459-280-1	2	2	-	280" x 3/8" -8JIC/-8JIC Hose (w/Cordura & 26.5" Collar)
23	35-42459-280-2	2	-	-	280" x 3/8" -8JIC/-8JIC Hose (w/Cordura & 23.5" Collar)
24	44-14734	2	1	-	Plate, Retainer
25	44-16236	1	1	-	Plate, Coupler Mount
26	70-20604	2	2	-	1/2" Center Lock Hex Nut
27	70-20611	1	1	-	5/16" Nyloc Hex Nut Gr. 5
28	70-20622	4	2	-	3/8" Flange Hex Nut Gr 5 NC



Colored Lines = Quantity of Colored Spiral Bands



Contact Us

As always, if you have any questions about your FH-440 XR Front Hitch or other products made by Grouser, feel free to contact us.

Grouser Products

755 2nd Ave NW - West Fargo, ND 58078

Phone: 1-701-282-7710

Fax: 1-701-282-8131

E-mail: info@grouser.com

Website: www.grouser.com

Improvements

Grouser Products Inc. is continually striving to improve its products. We reserve the right to change prices, specification, or equipment at any time without notice. We also reserve the right to make improvements or changes when it becomes practical and possible to do so without incurring any obligation to make changes or additions to the equipment sold previously.

Warranty

Grouser Products warrants to the original purchaser of each item that the product be free from defects in material and workmanship under normal use and service for a period of two years. If such equipment is found to be defective within two years, it is the obligation of Grouser Products under this warranty to repair or replace (exclusive of the cost of labor and transportation), any equipment or parts, in the judgment of Grouser Products to be defective in material or workmanship.

All equipment or parts claimed to be defective in material or workmanship must be made available for inspection at the place of business of a dealer authorized to handle the equipment covered by this warranty, or, upon request by Grouser Products, shipped to the Grouser Products factory in West Fargo, North Dakota. Grouser Products shall have no obligation to bear the cost of labor or transportation in connection with replacement or repair of any such defective parts in the setup process.

This warranty covers only defects in material and workmanship. It does not cover depreciation or damage caused by normal wear, accident, improper assembly, improper adjustments, improper maintenance including lack of proper lubrication, or improper use. Therefore, Grouser Products liability under this warranty shall not be effective or actionable unless the equipment is assembled, maintained and operated in accordance with the operating instructions accompanying the equipment. Grouser Products shall have no liability if the equipment has been altered or reworked without the written authorization of Grouser Products.

Grouser Products' parts, which are furnished under this warranty and properly installed, shall be warranted to the same extent as the original parts under this warranty if, and only if, such parts are found to be defective within the original warranty period covering the original equipment.

