

FH-400 John Deere 7030 Series - Non-Suspended

Undercarriage Installation Instructions

Caution:

- Always use precaution when working around any equipment.
- Always wear safety glasses.
- Follow tractor manufacturer's safety guidelines when installing this product.
 - **1.** Read all instructions prior to installation.
 - 2. Remove weights and weight bracket from front of tractor if necessary.
 - 3. Position the undercarriage (U/C) under the tractor and center with the frame of the tractor.
 - 4. Lift the U/C until the holes on the U/C line up with the front weight bracket mounting holes.
 - **5.** At the front of the tractor, start 6 20mm x 70mm bolts (PN: 16-1876) with a large 3/4" washer (PN: 57-3680) on each bolt in the holes of the U/C and into the holes in the front of the tractor. See attached diagram for clarification.
 - 6. Attach the left and right rails to the left and right sides of the undercarriage with 3 1" x 2-1/2" bolts (PN: 16-20560), 6 1" heavy duty flat washers (PN: 57-20819), and 3 1" nuts (PN: 70-20599) for each side. Hand tighten only. See attached diagram for clarification.
 - **7.** Start 2 20mm x 70mm bolts (PN: 16-1876) with a 3/4" ID washer (PN: 57-3680) on each bolt through the front holes of the left and right rail and the tractor frame.
 - **8.** Start 2 20mm x 50mm bolts (PN: 16-1878) with a 3/4" ID washer (PN: 57-3680) on each bolt through the rear holes of the left and right rail and the tractor frame. See attached diagram for clarification.
 - **9.** Once all bolts are installed, torque the front 20mm bolts to 432 ft-lbs., the remaining 20mm bolts to 432 ft-lbs., and all 1" bolts to 903 ft-lbs.
- **10.** Install push pole (PN: 17-3784) with 1" pin (PN: 43-3472), 1" flat washer (PN: 57-20749), and pin clip (PN: 43-7767). Place shims (PN: 44-7221) between rear of push pole and drawbar for tight fit.
- **11.** After first 8 hours of use, re-torque all bolts.
- **12.** Check all fasteners regularly to ensure proper operation of equipment.

				-(2,13)	4		
			Description				
1 2	10	16-1876 16-1878	20mm x 2.5mm x 70mm Metric Hex Bolt Gr 10.9 20mm x 2.5mm x 50mm Metric Hex Bolt Gr 10.9				
2	4 6	16-1878	1" x 2-1/2" Hex Bolt Gr 8 NC				
4	1	17-3784	JD 7020, 7030 Large Frame Push Pole 60"				
5	1	43-3472	1" x 3.12" Welded Pin w/ Holes and Washer				
6		43-7767	Hitch Clip Pin				
7		44-7221	FH-400 Push Pole Shim 1/8"			ח∩םם	UCTS INC.
8			JD 7030 Side Rail Left	G		Ave NW	Phone 701.282.7710
9	1		JD 7030 Side Rail Right		West Far	go, ND 58078 ROUSER.COM	Fax 701.282.8131
10	1		FH-400 UC JD 7020, 7030 Large Frame			KUUSEK.CUIVI	
11	1	57-20749	1" Flat Washer	TITLE:	H-400 U/C	0	
12	12	57-20819	1" Flat Washer Heavy Duty Gr 8 (USS)	J	ID 7030 Nor	<u>n-Susper</u>	nded
13		57-3680	2.00" OD x .75" ID x .375" Thick CZ Plating	Date:	2/25/2008	DWG. NO.:	11670
14	6	70-20599	1" Hex Nut Gr 8 NC		2,20,2000		11070