

## FH-400 Agco DTA Series

## **Undercarriage Installation Instructions**

## Caution:

- Always use precaution when working around any equipment.
- Always wear safety glasses.
- Follow tractor manufacturer's safety guidelines when installing this product.
  - 1. Read all instructions prior to installation.
  - 2. Remove weights and mounting bracket from front of tractor. Bolts will be reused for mounting the undercarriage (U/C).
  - 3. Position the U/C under the tractor and center with the frame of the tractor.
  - 4. Lift the U/C until the holes on the U/C line up with the front weight bracket mounting holes.
  - 5. At the front of the tractor, use the weight mount bracket bolts to attach the U/C to the front of the tractor.
  - **6.** Attach the right rail (PN: 46-11541-R) to the right side of the tractor frame with 2 20mm bolts (PN: 16-1876) and 2 3/4" flat washers (PN: 57-20747). See attached diagram for clarification.
  - Attach the left rail (PN: 46-11541-L) to the left side of the tractor frame with 2 20mm bolts (PN: 16-1876) and 2 - 3/4" flat washers (PN: 57-20747). See attached diagram for clarification.
  - 8. Attach the right rail to the right side of the undercarriage with 3 1" bolts (PN: 16-20558), 6 1" heavy duty flat washers (PN: 57-20819), and 3 1" nuts (PN: 70-20599). See attached diagram for clarification.
  - **9.** Attach the left rail to the left side of the undercarriage with 3 1" bolts (PN: 16-20558), 6 1" heavy duty flat washers (PN: 57-20819), and 3 1" nuts (PN: 70-20599). See attached diagram for clarification.
- **10.** Once all bolts are installed, torque the front bolts to 432 ft-lbs., all 20mm bolts to 432 ft-lbs., and all 1" bolts to 903 ft-lbs.
- **11.** Adjust drawbar to the furthest forward hole.
- **12.** Install push pole (PN: 17-3396) with 1" pin (PN: 43-3472), 1" flat washer (PN: 57-20749), and a pin clip (PN: 43-7767). Place shims (PN: 44-7221) at end of push pole until it is tight against the drawbar.
- **13.** After first 8 hours of use, re-torque all bolts.
- **14.** Check all fasteners regularly to ensure proper operation of equipment.

The Reservation of the Delawate is the Sole Property of REVISIONS: The Wartest results on view of process resources are of the delay							
Item No.	Qty.	Part No.	Description	1			
1	4	16-1876	20mm x 2.5mm x 70mm Metric Hex Bolt Gr 10.9				
2	6	16-20558	1" X 2" Hex Bolt Gr 8 NC	ļ			
3	1	17-3396	FH-400 Massy 8200, Agco DT, Cat 600A/B Series - Push Pole (64.34")	ļ			
4	1	43-3472	1" x 3.12" Welded Pin w/ Holes & Washer				_
5	1	43-7767	3/16 X 3 -1/4 X 7/8" Hitch Pin Clip 5/8 -1" SHAFT .177 WIRE	GROL	ISER PRODU	UCTS INC	C.
6	8	44-7221 46-11541-L	FH-400 Push Pole Shim 1/8" FH-400 Massy 8400, Cat 600B Series Side Rail - Left		5 2nd Ave NW	Phone 701.282.77 ax 701.282.813	10
8	1		FH-400 Massy 8400, Cat 600B Series Side Rail - Leit		<u>vw.grouser.com</u>	1	JI
9	1	54-3394	FH-400 UC Massy 8200, Agco DT, Agco 9700, Cat 600A/B Series	TITLE FH-400 Age	co DTA	DWG. NO.	
10	4	57-20747	3/4" Flat Washer	Series UC A	Assv	3394-A	
10	1	57-20749	1" Flat Washer				·
12	12	57-20819	1" Flat Washer Heavy Duty Gr 8 (USS)	Date:	Scale:	Sheet:	
13	6	70-20599	1" Hex Nut Gr 8 NC	2-25-2008	1:16		1