

450 Case STX 275, 330 AccuSteer

Undercarriage Installation Instructions

Caution:

- Always use precaution when working around any equipment.
- Always wear safety glasses.
- Follow tractor manufacturer's safety guidelines when installing this product.
 - 1. Read all instructions prior to installation.
 - 2. Remove existing toolboxes and tow cable holder if equipped.
 - 3. Position the undercarriage (U/C) under the tractor and center with the frame of the tractor.
 - **4.** Raise the front of the U/C to within 1/2" from the frame of the tractor.
 - **5.** Start 4 20mm x 90mm bolts (PN: 16-1510) with a large washer (PN: 57-8836) on each bolt from the bottom in the slots at the front of the U/C. Tighten the bolts until the washers contact the U/C. See attached diagram for clarification.
 - **6.** Raise the trear of U/C and install the 4 20mm x 50mm bolts (PN: 16-1878) with a 3/4" flat washer (PN: 57-20747) on each bolt.
 - **7.** Torque all 20mm bolts to 432 ft-lbs.
 - 8. Use the side frame holes as guides and drill 6 1" holes through the side of the tractor frame.
 - Caution: When drilling, be aware of all parts behind the material being drilled so that you do not mistakenly hit or puncture components on engine side of tractor frame.
 - **9.** Install 6 1" x 2-1/2" bolts (PN: 16-20560) with a 1" heavy washer (PN: 57-3682) in the previously drilled holes. See attached diagram for clarification.
- 10. After the 6 1" bolts are through the tractor frame, attach with a 1" nut (PN: 70-20599) on each bolt.
- 11. Torque all 1" bolts to 903 ft-lbs.
- **12.** After first 8 hours of use, re-torque all bolts.
- **13.** Check all fasteners regularly to ensure proper operation of equipment.

PN: 63-11422-INS 1 Date: 11-3-2011

