

760 - Steiger / TJ Wheeled 350,400,450

Undercarriage Installation Instructions

Caution:

- Always use precaution when working around any equipment.
- · Always wear safety glasses.
- Follow tractor manufacturer's safety guidelines when installing this product.
 - 1. Read all instructions prior to installation.
 - 2. Remove existing toolboxes, front weights, and tow cable holder if equipped. If a tow cable bracket was purchased from Grouser, then the tow cable can be reinstalled later.
 - **3.** If the bottom covers (PN: 44-14242-R,L & 44-14306) are not factory installed, attach to U/C with 1/2" x 1-1/4" bolts (PN: 16-20125) and 1/2" flat washers (PN: 57-20744). See attached diagram for clarification.
 - **4.** If the bulkhead bracket (PN: 18-14249) is not factory installed, attach to the U/C with 2 1/2" x 1-1/4" bolts (PN: 16-20125) and 1/2" flat washers (PN: 57-20744). See attached diagram for clarification. See parts book for bulkhead fittings, steel lines, and hose locations.
 - **5.** If bulkhead covers (PN: 44-14246 & 44-14247) are not factory installed, verify that all hydraulics are installed correctly and then attach the covers to the U/C with 6 1/2" x 1-1/4" bolts (PN: 16-20125) and 1/2" flat washers (PN: 57-20744). See attached diagram for clarification.
 - **6.** Position the undercarriage (U/C) under tractor and center on the frame of the tractor.
 - 7. Lift the rear of the U/C up and set the top plates of the U/C on the cross member. Push the U/C back until the vertical push plates are firmly against the cross member. Lift the U/C to within 3/4" of touching the tractor frame.
 - **8.** Insert 8 20mm x 90mm bolts (PN: 16-1510) with a 3/4" hardened flat washer (PN: 57-20757) on each bolt through the front holes of the tractor frame that line up with the front vertical holes of the U/C.
 - **9.** After all bolts are through the tractor frame and U/C, attach with a 3/4" heavy washer (PN: 57-3680) and a 20mm nut (PN: 70-20872-10). Verify that the rear of the U/C is firmly against the cross member. Tighten until frame is tight vertically.
- **10.** Attach the upper support arms (PN: 11-14240-R,L) to the U/C with 2 1" x 3-1/2" bolts (PN: 16-20564), 4 1" heavy duty flat washer (PN: 57-20819), and 2 1" nuts (PN: 70-20599) on each side of the U/C. See attached diagram for clarification.
- **11.** Attach the upper support arms to the tractor with a 1-1/4" x 3-1/2" bolt (PN: 16-20896), 4 1-1/4" flat washers (PN: 57-11671), and a 1-1/4" nut (PN: 70-20981) in the bottom hole on each side. See attached diagram for clarification.
- **12.** Once all bolts have been installed, torque the front 20mm vertical bolts to 432 ft·lbs., the 1" bolts to 903 ft·lbs., and the 1-1/4" bolts to 1,105 ft·lbs.
- **13.** After first 8 hours of use, re-torque all bolts.
- **14.** Check all fasteners regularly to ensure proper operation of equipment.

PN: 63-14340-A 1 Date: 6-8-2011

