

FH-400 John Deere 8RT

Undercarriage Installation Instructions

Caution:

- Always use precaution when working around any equipment.
- Always wear safety glasses.
- Follow tractor manufacture's safety guidelines when installing this product.
 - **1.** Read all instructions prior to installation.
 - 2. Remove weights and weight bracket from front of tractor if necessary.
 - 3. Position the undercarriage (U/C) under the tractor and center with the frame of the tractor.
 - 4. Lift the U/C until the holes on the tractor line up with the U/C holes.
 - **5.** At the front of the tractor, use 4 20mm x 70mm bolts (PN: 16-1876) with a 3/4" washer (PN: 57-20747) on each bolt to attach the U/C to the front of the tractor. See attached diagram for clarification.
 - 6. Raise rear of undercarriage until holes on the tractor line up with the U/C holes. Be sure that the U/C is tight against the tractor.
 - 7. Attach rear of U/C to tractor with 4 20mm x 60mm bolts (PN: 16-2487) with a 3/4" washer (PN: 57-20747) on each bolt.
 - 8. Attach the left and right side rails (PN: 44-14865) to the left and right sides of the U/C with 6 3/4" x 2-1/4" bolts (PN: 16-20219), 12 3/4" flat washers (PN: 57-20747), and 6 3/4" nuts (PN: 70-20607) for each side rail. See attached diagram for clarification.
 - **9.** Start 6 16mm x 75mm bolts (PN: 16-1620075) with a 16mm flat washer (PN: 57-20825) on each bolt through the top holes of the left and right rail and the tractor frame. See attached diagram for clarification.
- **10.** Start 2 20mm x 70mm bolts (PN: 16-1876) with a 3/4" flat washer (PN: 57-20747) on each bolt through the lower two holes of the left and right rail and the tractor frame. See attached diagram for clarification.
- **11.** Once all bolts are installed, torque all 20mm bolts to 432 ft-lbs., all 16mm bolts to 269 ft-lbs., and all 3/4" bolts to 257 ft-lbs.
- 12. After first 8 hours of use, re-torque all bolts.
- **13.** Check all fasteners regularly to ensure proper operation of equipment.

