

PL-4100 John Deere 60 & 70 Series

Undercarriage Installation Instructions

Caution:

- Always use precaution when working around any equipment.
- Always wear safety glasses.
- Follow tractor manufacturer's safety guidelines when installing this product.
 - **1.** Read all instructions prior to installation.
 - 2. Remove the axle to frame brace (8960 model only) and remove the pull hook (all models). Keep the hardware to attach the undercarriage (U/C). See attached diagram for clarification.
 - **3.** Position the U/C under the tractor and center with the frame of the tractor.
 - 4. Lift the U/C until the holes on the U/C line up with the tractor frame holes.
 - **5.** Attach the U/C to the tractor axle housing with the 24mm x 150mm bolts (PN: 16-1875) and a 1.05" I.D. washer (PN: 57-3098) on each bolt. Hand tighten only until all bolts are installed.
 - **6.** Insert a 7/8" bolt (PN: 16-20538) with a 7/8" flat washer (PN: 57-20818) on each bolt into the remaining holes on the U/C and the tractor frame. See attached diagram for clarification.
 - 7. After all bolts are installed, attach with a 7/8" nut (PN: 70-20598) on each bolt.
 - 8. Torque all 24mm bolts to 909 ft-lbs., and torque the 7/8" bolts to 350 ft-lbs.
 - **9.** After first 8 hours of use, re-torque all bolts.
- **10.** Check all fasteners regularly to ensure proper operation of equipment.

PN: 63-9511-INS 1 Date: 6-10-2008

