

## **PL-41 Case 9200,9300 Long Frame**

## **Undercarriage Installation Instructions**

## Caution:

- Always use precaution when working around any equipment.
- Always wear safety glasses.
- Follow tractor manufacturer's safety guidelines when installing this product.
  - **1.** Read all instructions prior to installation.
  - 2. Remove existing toolboxes and weights if equipped.
  - 3. Position the undercarriage (U/C) under tractor, center on the frame of the tractor.
  - **4.** Raise U/C up until the rear stops of the U/C are tight against the cross bar near the center of the tractor. **Be sure that the vertical push plates are firmly against the cross member.**
  - **5.** Use the rear of the U/C as a guide and drill 2 1-1/16" holes into the bottom of the tractor frame.
    - Caution: When drilling, be aware of all parts behind the material being drilled so that you do not mistakenly hit or puncture components on engine side of tractor frame.
  - **6.** Install 2 1" x 2-1/2" bolts (PN: 16-20560), 4 1" washers (PN: 57-20819), and 2 1" nut (PN: 70-20599) into the holes previously drilled holes. Hand tighten the bolts. See attached diagram for clarification.
  - **7.** Raise the front of the U/C up until the rear hole of the mounting plate is 2" above the tractor side frame. Check for clearance inside of frame rails
  - **8.** Use the U/C as a guide and drill 8 1-1/16" holes into the side of the tractor frame.
  - **9.** Install 8 1" x 2-1/2" bolts (PN: 16-20560) with a 1" washer (PN: 57-20819) on each bolt into each of the previously drilled holes. See attached diagram for clarification.
- 10. After all 8 bolts are through the tractor frame, attach with a 1" washer and 1" nut (PN: 70-20599).
- 11. Torque all 1" bolts to 903 ft·lbs.
- **12.** After first 8 hours of use, re-torque all bolts.
- **13.** Check all fasteners regularly to ensure proper operation of equipment.

PN: 63-9514-INS 1 Date: 1-15-2008

