


PL4100 - NEW HOLLAND 9200

**INSTRUCTIONS:**

1. ENLARGE EXISTING HOLES IN TRACTOR FRAME BY DRILLING THEM OUT FOR 1" CAPSCREWS.
2. POSITION UNDERCARRIAGE INTO PLACE, CENTERING ON THE TRACTOR FRAME AND ALIGNING UNDERCARRIAGE HOLES TO EXISTING TRACTOR HOLES. INSTALL HARDWARE WITHOUT TIGHTENING.
3. LOCATE REAR OF UNDERCARRIAGE AS SHOWN AND DRILL HOLE FOR 1" CAPSCREW THROUGH TRACTOR SIDE PLATE USING UNDERCARRIAGE AS A GUIDE. DRILL REMAINING HOLE IN FRONT SIDE PLATE.
4. INSTALL ALL REMAINING HARDWARE AND TIGHTEN.

 <b>GROUSER PRODUCTS</b> BOX 545 ..... WEST FARGO, N.D. 58078      PHONE 701 282-7710				
DRAWN BY	CHECKED BY	WHERE USED	SCALE	DATE
BJG		FORD 9200	1:16	9/28/98
<small>NOTICE: THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND IT SHALL NOT BE USED OR REPRODUCED OR ITS CONTENTS DISCLOSED, IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF GROUSER PRODUCTS, INC.</small>				
<small>TITLE</small> <b>MOUNTING INSTRUCTIONS</b>			<small>PART NO.</small> <b>8811</b>	

CAD DRAWING