

450 Case 9200,9300 Long Frame

Undercarriage Installation Instructions

Caution:

- Always use precaution when working around any equipment.
- Always wear safety glasses.
- Follow tractor manufacturer's safety guidelines when installing this product.
 - 1. Read all instructions prior to installation.
 - 2. Remove existing toolboxes and weights if equipped.
 - 3. Position the undercarriage (U/C) under tractor, center on the frame of the tractor.
 - **4.** Raise U/C up until the rear stops of the U/C are tight against the cross bar near the center of the tractor. **Be sure that the vertical push plates are firmly against the cross member.**
 - **5.** Use the rear of the U/C as a guide and drill 2 1-1/16" holes into the bottom of the tractor frame.

Caution: When drilling, be aware of all parts behind the material being drilled so that you do not mistakenly hit or puncture components on engine side of tractor frame.

- **6.** Install 2 1" x 2-1/2" bolts (PN: 16-20560), 4 1" washers (PN: 57-20819), and 2 1" nut (PN: 70-20599) into the holes previously drilled holes. Hand tighten the bolts. See attached diagram for clarification.
- **7.** Raise the front of the U/C up until the rear hole of the mounting plate is 2" above the tractor side frame. Check for clearance inside of frame rails.
- **8.** Use the U/C as a guide and drill 8 1-1/16" holes into the side of the tractor frame.
- **9.** Install 8 1" x 3-1/2" bolts (PN: 16-20564) with a 1" washer (PN: 57-20819) on each bolt into each of the previously drilled holes. See attached diagram for clarification.
- **10.** After all 8 bolts are through the tractor frame, attach with a 1" washer and 1" nut (PN: 70-20599).
- **11.** Torque all 1" bolts to 903 ft·lbs.
- **12.** After first 8 hours of use, re-torque all bolts.
- **13.** Check all fasteners regularly to ensure proper operation of equipment.

